

BGSU Sling Inspection Checklist

Sling Type:	Serial #:	Rated Capacity:
-------------	-----------	-----------------

Competent Person:	Location:	Date:
-------------------	-----------	-------

INSTRUCTIONS: Check all items listed and indicate yes, no, or not applicable. If any items are marked "Yes" for deficient, the sling must be removed from service until repaired and proof tested by the sling manufacturer or equivalent entity.

Deficiency	Yes	No	N/A
Missing/illegible identification or markings			
Cracks or breaks			
Broken wires, fibers, or welds			
Excessive wear, nicks, gouges, holes or tears			
Stretched, bent, twisted, knots, deformed chain links or fittings			
Chain link size below minimum diameter (appendix G)			
Kinking, crushing, birdcageing			
Evidence of heat, chemical or UV damage			
Excessive pitting or corrosion			
Chain or fittings unable to hinge freely			
Wire mesh lack of flexibility/distorted			
Weld splatter present			
Other conditions, including visible damage			

Description of defects found:

Signature:	Department:
------------	-------------